

## INSTRUCTIONS, SAFETY AND WARRANTY GUIDE

Congratulations on the purchase of your Express Gold Curl™ curling iron. We hope you enjoy all of its features, benefits and styling capabilities!

- Please make sure to read this guide thoroughly before use
- Please keep this guide in a handy place for quick reference

### **FEATURES**

- Gold surface distributes heat evenly for consistent, long-lasting curls
- Adjustable temperature control; tool quickly heats up to 430°F
- Dual voltage for worldwide use
- Extra-long cool tip and insulated thumb grip ensure comfort and total control
- Includes 1 free replacement spring
- Locking temperature dial for safe operation
- Durable safety stand
- Power indicator light
- 9-foot professional length swivel cord
- 1-year warranty from date of purchase

### **OPERATING INSTRUCTIONS**

Press the power button (⏻) once to turn on. To adjust the heat setting, press the temperature dial to allow it to pop out. Turn the dial to your desired heat setting and push the dial back in to lock it.

The curling iron will reach your selected temperature in three minutes. Once you have finished curling, press the power button (⏻) to turn off and unplug the tool. This iron is intended for professional and consumer use. This iron has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit into a polarized outlet only one way. If the plug does not fit securely, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

### **STYLING TIPS**

- Make sure hair is completely dry before use.
- Use a comb when styling for best results.
- Take small sections of hair for optimum results.


TEMPERATURE SETTING	HAIR TYPE
280 - 320°F	Fragile, fine, thin hair
320 - 380°F	Normal, medium hair
380 - 410°F	Thick, coarse hair
410 - 430°F	Professional use only

- Take a section of hair (the smaller the section, the tighter the curl).
- Clamp the ends of this section in between the barrel and the clamp holding the barrel vertically. Wrap your hair around the barrel.
- For fine hair: hold the iron in place for 5 to 8 seconds. For thick hair: hold the iron in place for 10 – 15 seconds.
- To release the curl, press the thumb grip to release the ends of your hair. Gently pull the barrel out of the curled section and then twirl the barrel counterclockwise, until the curl slips off the top of the barrel.
- Allow curls to cool before combing or brushing.
- Turn the iron off before unplugging it.

## SPRING REPLACEMENT INSTRUCTIONS

Turn off the iron and unplug it, ensuring it has cooled completely before replacing the spring.

1. **Remove the screws from the barrel:** Hold the iron by the barrel and push down gently on the thumb grip. Use a small Phillips screwdriver to remove one screw, then the other.



2. **Remove the old spring from the barrel:** Using a small Phillips screwdriver, gently loosen the screw—a quarter or half turn counterclockwise should remove the screw. Pinch the spring's coils together and pull the spring out of the bracket.
3. **Insert the new spring:** Pinch the new spring's coils together and insert it into the bracket. Do not push the spring in as far as it will go, but leave a small portion of the rods extending from the bracket.
4. **Tighten the bracket screw carefully, keeping the new spring straight on the barrel.**
5. **Replace the clamp:** Holding the iron by the barrel, align the clamp's screw holes with the screw holes in the barrel. Insert each screw.
6. **Test the clamp several times to ensure the iron works properly.**

## GENERAL SPECIFICATIONS

	0.75" Model GI75NA	1" Model GI10NA	1.25" Model GI12NA	1.5" Model GI15NA
Rated Wattage	35W	40W	50W	60W
Rated Voltage(V)	120V~	120V~	120V~	120V~
Frequency(Hz)	60Hz	60Hz	60Hz	60Hz
Weight (g)	245g / 8.64 oz. (0.54 lbs.)	285g / 10.05 oz. (0.62 lbs.)	315g / 11.11 oz. (0.69 lbs.)	385g / 13.58 oz. (0.84 lbs.)
Length of A.C. Cord	9ft / 2.7m	9ft / 2.7m	9ft / 2.7m	9ft / 2.7m

## IMPORTANT SAFETY INSTRUCTIONS

### **READ ALL INSTRUCTIONS BEFORE USING.**

**DANGER** – Any appliance is electrically live, even when the switch is off. When not in use, always unplug the iron to prevent the risk of fire.

**WARNING** – To reduce the risk of burns, electrocution, fire, or injury to persons and/or personal property:

- Use the iron only for the purpose described in this guide to prevent accidents, damage or malfunction.
- This appliance should never be left unattended when plugged in.
- Plug the iron into an electrical outlet of AC 120V/60Hz.
- Avoid multiple cables to a plug or use of an extension cord to prevent starting a fire from overheating.
- KEEP AWAY FROM WATER to prevent fire, electric shock, damage or malfunction.
- KEEP AWAY FROM CHILDREN.
- Do not handle the iron or cord with wet hands as this may cause electric shock.
- Do not leave the iron in a position where it can fall or be pulled into a tub or sink.

- Keep the cord away from heated surfaces.
- DO NOT WRAP THE CORD AROUND THE IRON.
- Never place or insert objects on iron barrel, due to the risk of causing fire, accidents or malfunction.
- Do not operate where oxygen is being administered, to avoid the risk of fire.
- DO NOT USE WHEN CORD HAS BEEN DAMAGED OR IF PLUG IS LOOSE.
- DO NOT REPAIR, TAMPER WITH, OR TRY TO RECONSTRUCT the iron, otherwise electric shock, malfunction or accidents may result.
- When inserting or pulling out the plug, hold the plug firmly to prevent the cord from peeling and to prevent accidents or malfunction.
- Stop using immediately if you smell an offensive odor. If ignored, it could cause a fire or other accidents.
- Do not keep the iron in a damp place, such as a bathroom, or it may malfunction.
- Stop using the iron and remove from the power source when there is an earthquake or thunder.
- Unplug the iron from the power source when cleaning or wiping to prevent fire or electric shock.
- DO NOT use this tool on synthetic hair.
- NEVER clean this device with liquid cleaners, aerosol cleaners, or cleaners containing detergents, abrasive or corrosive materials.
- NEVER use this device for purposes other than those intended by the manufacturer.
- NEVER operate this device if there is a damaged cord or plug, the unit is not working properly, has been dropped, damaged, or exposed to water.
- Always keep this device and cord away from water AND heated surfaces.
- NEVER wrap the cord around the device.
- NEVER leave this product unattended when plugged in.
- DO NOT operate this product around children or pets; do not operate around aerosol products or where oxygen is being administered.
- Barrel is HOT. Avoid contact with skin or other sensitive body areas. Use ONLY on hair.
- DO NOT place a hot or cooling device on any unprotected surface; never place the device barrel-side down.

### **MAINTENANCE**

**Daily Maintenance:** For the safe use of the iron, check the following daily:

- Check the cord and surface of the cord. Never use if any parts are cracked, split, torn, or damaged.
- Check the plug and never use if cracked, split, or damaged.
- Check the plug pins and never use if transformed or damaged.
- Check the controller and do not use if cracked, split, broken, or damaged.
- When not in use, clean and dry the entire iron and store in a cool, dry place.

When ready to use, follow the directions for daily maintenance.

**Daily Cleaning:** To keep the barrel clean, unplug the iron from the power source. Once the barrel is cool, wipe it down after each use with a hot, damp towel.

**WARNING:** Do not wipe the iron with thinner, benzene, gasoline, lamp oil, and other solvents or chemicals, as that may cause accidents or malfunction, or damage the iron and void the warranty.

### **Defects and Malfunction**

- Read all contents of the warranty completely and carefully before contacting the salon, the distributor, or [pmprottools@paulmitchell.com](mailto:pmprottools@paulmitchell.com) 1-888-522-8622.

- The iron is covered under under limited warranty for 12 months from the date of purchase.
- John Paul Mitchell Systems® is not responsible for damage caused by misuse or due to operator accidents, such as dropping the appliance on the floor.

## WARRANTY RETURN PROCEDURE

For all warranty issues please call 1-888-522-8622 or email us at [pmprotocols@paulmitchell.com](mailto:pmprotocols@paulmitchell.com) for further instructions and a return address.

## WARRANTY GUIDE

### IMPORTANT WARRANTY NOTICE

**A purchase receipt is required for all warranty claims.  
(Please read details below)**

**IMPORTANT: Warranty valid only when appliance is purchased from an authorized PAUL MITCHELL® salon or distributor. Warranty valid only for the Express Gold Curl™.**

**Terms and conditions may vary depending on salon/authorized retailer's individual exchange or return policy.**

#### LIMITED 12-MONTH WARRANTY

Our 12-month warranty covers tools within the U.S. (Alaska, Hawaii, Puerto Rico and Continental U.S.) and Canada only, and only when purchased from an authorized PAUL MITCHELL® salon or distributor. The Paul Mitchell® Pro Tools™ warranty covers the appliance against defects in material or workmanship for 12 months from date of purchase.

Sorry, no refunds will be given.

#### THIS WARRANTY DOES NOT COVER

- Damage due to any modifications to the appliance
- Normal wear and tear, which includes, but is not limited to, housing or barrel scratches, shorts or cuts in the power supply cord or plug
- Damage due to misuse and abuse such as:
  - Dropping
  - Wrong voltage supply
  - Neglecting safety precautions
- Tampering, such as repair or attempted repair by unauthorized party
- Neglect or lack of proper maintenance
- Damage to cord. Please do not wrap the cord around the iron as it can result in the cord breaking.

PLEASE BE ADVISED THAT IMPROPER USE OR MAINTENANCE OF YOUR APPLIANCE CAN RESULT IN DAMAGE TO PROPERTY OR PERSONAL INJURY INCLUDING GREAT BODILY HARM. IT IS IMPORTANT TO FOLLOW THE INSTRUCTIONS. FAILURE TO DO SO CAN VOID THIS WARRANTY.

#### WITH PROOF OF PURCHASE AND WITHIN 12 MONTHS

Exchange of defective appliance is at Paul Mitchell's discretion. If your Paul Mitchell® Pro Tools™ appliance fails to operate properly within the first 12 months of purchase, consumers can return the iron to the salon where it was purchased (**terms and conditions may vary depending on salon/authorized retailer's individual exchange or return policy**), and stylists can return it to their distributor, making sure to bring the original proof of purchase. Otherwise, please call 1-888-522-8622 or e-mail us

at pmprotocols@paulmitchell.com for further instructions. For replacement of appliance under warranty, there is a \$14.00 (USD) fee payable to Paul Mitchell® Pro Tools™ to cover shipping, handling and insurance to send your replacement appliance to you.

Repair or servicing of defective appliances is not offered.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE 12-MONTH DURATION OF THIS WRITTEN LIMITED WARRANTY.

IN NO EVENT SHALL JOHN PAUL MITCHELL SYSTEMS® BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, WHATSOEVER.

This warranty gives you specific legal rights, and you may also have other rights, which may vary from state to state both in the U.S.A. and Canada.

**Guaranteed ONLY when purchased within the professional beauty salon industry, NOT from a drugstore, supermarket, or other unauthorized source.**

express gold  
**curl**

## GUIDE D'UTILISATION, DE SÉCURITÉ ET DE GARANTIE

Félicitations pour votre achat de la brosse de coiffage thermique Express Gold Curl™ (Fer à coiffage). Nous espérons que vous apprécierez toutes ses fonctions, avantages et capacités de coiffage!

- Veuillez lire ce guide attentivement avant d'utiliser l'appareil
- Veuillez conserver ce guide à portée de main pour vous y référer rapidement

### **CARACTERISTIQUES**

- La surface dorée distribue la chaleur uniformément pour des boucles homogènes et durables
- Contrôle réglable de la température ; chauffe rapidement jusqu'à 221° C (430° F)
- Bitension pour une utilisation dans le monde entier
- Pointe froide extra-longue et poignée ergonomique isolée garantissant un confort et un contrôle total
- Comprend 1 fer à boucler de rechange gratuit
- Cadran de réglage de la température verrouillable pour une utilisation en toute sécurité
- Support de sécurité durable
- Voyant d'alimentation
- Cordon rotatif professionnel d'une longueur de 2,75 m (9 pieds)
- Garantie de 1 an entrant en vigueur à la date d'achat

### **CONSEILS D'UTILISATION**

Appuyer sur le bouton (⏻) Marche/Arrêt pour mettre l'appareil en marche. Pour régler la température, appuyer sur le cadran de réglage de la température pour lui permettre de ressortir. Tourner le cadran jusqu'à la température souhaitée et le renfoncer pour le verrouiller.

Le fer à boucler atteindra la température sélectionnée en trois minutes. Après avoir terminé d'utiliser le fer, appuyer sur le bouton (⏻) Marche/Arrêt pour éteindre l'appareil avant de le débrancher. Ce fer est prévu pour une utilisation professionnelle et personnelle.

Cet appareil possède une prise polarisée (une fiche est plus large que l'autre).

Par mesure de sécurité, cette prise ne s'insère dans une prise de courant polarisée que dans un seul sens.

**PAUL MITCHELL** protools™